## **Active+ Sense**

## **ROCKGATE**

The Active+ Sense is a small luminaire-based sensor that combines a light sensor for constant light control and a passive infrared movement detector

This sensor can be used on the intelligent luminaire stand-alone control solution Active+.


The Active+ Sense plugs in the Active+ LED driver for Active+ usage.

If the sensor is connected to non-SELV control gear, the luminaire must be Class I.

### **Key Features**


- Small and inconspicuous, it does not change the appearance of the luminaire.
- Provided with mounting features that can be snapped into sheet metal: two on each long side, and two on the rear.

#### Light Sensor - For constant light functions




\* Max recommended height 3 m

#### Presence Detector - Passive infrared (PIR)





\* Max recommended height 4 m




- 1. PIR sensor
- 2. Light sensor

### Mounting Features





# Detection pattern at floor level for 2.5 meters mounting height



#### Technical Data

# **ROCKGATE**

Connections		
Active+:	Flexible cable terminated with a fourway, 2 mm keyed connector	
	<u> </u>	Note: If the sensor is connected to nonSELV control gear, the luminaire must be Class I.


Mechanical data		
Dimensions:	50 mm × 20 mm × 10 mm	
Weight:	12 g	
IP rating:	IP20	


Cable information	
Order Code: 3021010	Length: 80 cm, Colour: White

Operating and storage conditions			
Ambient temperature:	-20 °C to +50 °C		
	Note: The temperature difference between the detection target and the background must be at least 4 °C.		
Relative humidity:	Max. 85 %, non-condensing		
Storage temperature:	-20 °C to +70 °C		
Illuminance:	5 lx to 5000 lx		


Conformity and standards		
Conformity:	C € CA	
EMC emission:	EN 55015	
EMC immunity:	EN 61547	
Safety:	EN 61347-2-11	
Environment:	Complies with RoHS directive.	

### Connection






### Dimensions (mm)



## Mounting





Note: Sensor holders are available to be used with the Active+ Sense:

5691 - ActiveAhead Sense Rectangular Sensor holder 5692 - ActiveAhead Sense Circular Sensor holder